

Access Academy



Juno Tips and Tricks: Unboxing



Justine Taylor Low Vision Product Manager APH





Mike Wood

Strategic Accounts Manager-Education

enhanced vision Freedom Optelec TPGi

Learning Objectives

- The participant will:
 - Identify key components, parts and basic functioning of Juno's box contents.
 - Learn at least three important functions on the About screen including the steps on how to check Juno is up-to-date.
 - Gain knowledge in four aspects of System Settings; time and date, default save types, update device and reset device.







- Users need an introduction to Juno before getting started.
- The Juno requires customization to best benefit a user.





Poll Question #1

Where can you find the User Manual?

- Saved in Settings on Juno
- On the About Screen
- In the Box
- In default save types
- On the APH website





Juno Components

Access

Academy



• **1 Camera:** Rotate for multiple purposes

• **2 Power:** Short press to power on or put on standby, and long press to power down

• 3 & 4 Color mode: Move up or down through color modes


• **5 Capture:** Press to capture or return to Live view

• 6 & 7 Magnification: Increase or decrease zoom level

• 8 LCD screen: Touch to select




Juno Components continued







Juno Ports








Main Menu Structure









About Menu

Support

 Tap the Support icon on the About screen to display information for contacting Customer Support.

Manual

• Tap the **Manual** icon on the **About** screen to display the user guide.

Acknowledgements

• Tap the Acknowledgements icon on the About screen to display information about third-party software used to develop Juno.







Poll Question #2

Where is the About menu located?

- Settings
- User settings
- System settings
- Main menu





Check the Software Version Number

The most up-to-date software version for Juno is **2.0.36**. To check that your Juno has the most recent software version follow these steps:

- 1. Tap the RESTORE button bar icon in the bottom left corner of the screen
- 2. Tap the MAIN MENU icon
- 3. Tap the INFORMATION icc







System Settings



Tap the **System Settings** icon to display the **System Settings** screen, which has four options:

Time and Date



Update Juno 🚺

Access

Academy









How to use System Settings

Time and Date

• Set the date and time that the system displays in the upper right corner. If the battery fully discharges, then you will need to reset the date and time.

Default Save Types

• Select the default file type used when capturing pictures and the default file type used when capturing text.

Update Juno

 Update Juno with the latest software and firmware. You must download the latest Juno software onto a USB-C flash drive to perform this procedure. However, you can use the same flash drive to update multiple Juno devices.

Reset to Defaults

• Reset the device to the default values. All customized settings are lost, including the volume, speech rate, brightness level, and voice selection. However, the menu voice, date, and time are saved.





Poll Question #3

True or false: you can reset your device in System Settings.

- True
- False





Battery Status

Standby

• Press the white Power button briefly to put Juno in standby mode. The screen darkens and the processor is put in a lower power state. After five minutes of inactivity, Juno automatically goes into standby mode. Press the Power button to wake up the device.



Standby Time

To adjust this setting:

- Tap the **Restore** button , then tap the **Main Menu** button .
- Tap the Settings icon to display the Settings Menu.
- Tap the User Settings icon to display the User Settings screen.
- Tap the **Standby Time** icon to display the **Standby Time** screen.
- Swipe up or down and select the number of minutes that you want the system to remain idle before going into standby mode. The default is **5 minutes**.





Ending Polls

What topics would you like short tutorial videos for the Juno?

- Box contents
- Charging
- Updating device
- Resetting to defaults
- Other, write in the chat

Would you like a skills performance checklist to help with student progress monitoring for instruction on Juno?

- Yes, I would like this available
- No, not needed

Select what components of a skills performance checklist are important to you.

- All functions and elements of each menu screen
- Identifying buttons, ports and connections
- Just the top features
- Time and date of completing skill
- Pictures of icons
- Other, write in the chat





Discoveries

- Juno comes with a padded carrying case, screen cleaning cloth, power supply, charging cable and HDMI cable along with User and Quick Start guides.
- The most up to date software version can be found on the Juno product page on APH.org.
- You can set the time and date and change the default file using the System Settings menu.
- Juno can be updated with a download on a USB-C flash drive.
- Juno goes into Standby mode to save the three-hour battery life.






Juno

Access

Academy



- Quota Price: \$1,177.00
- Non-Quota Price: \$1,392.00



Complementary Products from APH and Vispero

VideoMag HD: \$539.00



Jupiter: \$3599.00

